

Even used batteries may cause severe injury or death.

Call a local poison control center for treatment information.

Only use new CR2032 batteries

3.0V

Non-rechargeable batteries are not to be recharged.

Do not force discharge, recharge, disassemble, heat above 70°C or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.

Designed in Canada by PowerStick.com.
Made in China.

Ensure the batteries are installed correctly according to polarity (+ and -)

Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.

Always completely secure the compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.

Do NOT dispose of batteries in household trash or incinerate.

Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.

Spot

Two-Way Bluetooth Finder




What is Spot?

Spot is a family of Bluetooth® trackers that you attach to your most important items to help keep track of them.

The Spot & the Spot app can alert you when you may be leaving something behind, can help you locate the item your Spot is connected to and can even help you find your phone.

Download the App

From the App Store (IOS) or Google Play (Android), search "Spot 2.0 Bluetooth Finder" & download the free app to your phone.



Getting Started

The in-app tutorial will guide you through:

- Logging in or Registering a new account
 - Pairing the Spot to your phone
 - Enabling the necessary permissions
- *Make sure your phone's Bluetooth® is turned on

Learn 5 Key App Features: Ring to Find Button

From the app, press the Ring to Find button to sound an alert from your Spot. Follow the sound to help locate your item.

Location History

Lost a Spot? Location History will map the last location your Spot was together with your phone. This is the last place they were connected and is likely where you left your Spot. It's a great place to start looking.

Mark as Lost

If a Spot is lost & shows disconnected, **Mark it as Lost**. The network of Spot users can help find it.

Out of Range Alerts

If this feature is enabled, your phone will sound an alert each time your phone and Spot get too far apart (out of range).

Questions? support@powerstick.com
Help? powerstick.com/main/spot-2-0-support

Warranty Offer
Register within 10 days of Receipt
www.powerstick.com/main/warranty

⚠ WARNING

INGESTION HAZARD • DEATH or serious injury can occur if ingested • A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as **2 hours** • KEEP new and used batteries **OUT OF REACH OF CHILDREN** • **Seek immediate medical attention** if a battery is suspected to have been swallowed or inserted in any part of the body.



ANSI/UL 4200 A
Reese's Law

Do not move or resize the warning text or symbols

06.27.24

Spot & Spot Pro (box card)

Instruction Card (BOX) Proof • Scale 1:1

Instructions:

- "Designed in Canada by PowerStick.com. Made in China." text must stay on all printed cards.
- Please embed any photos and outline any text used.
- The red guide is for the bleed. Any art that will reach the edge must be extended to the red bleed line.
- When creating a custom card, it is recommended to customize the front & leave the instructions on the rest of the pages to benefit the end user.